

The GMM Wireless Audio System

The wireless audio system is a hearing supplement for the Meeting room. A microphone located on the wall behind the facing bench picks up speech and transmits it through an infrared beam to the headset. If the volume control on the headset is turned up one may notice background noise. To avoid hearing the background noise, you can remove the headset between messages.

Stethoscope headsets

- 1) Open the headset and place it in your ears, so that it hangs down under your chin. This will activate the headset to receive the infrared audio signal.
 - 2) Make sure that the numbered volume control dial is facing outwards. Turn the dial for proper volume. Don't cover the dial with your hand because the infrared signal is received through the dial.
 - 3) When the service is over, please return the headset.
-

Headphone style headsets

- 1) Locate the power switch, and turn to the "on" position. Locate the volume control, a small dial facing edge outwards.
- 2) Place the headset on your ears.
- 3) Adjust the volume control for proper volume. Don't cover the headset earpieces with your hands because the infrared signal is received through the top of each earpiece.
- 4) When you remove the headset from your ears, turn the power switch to "Off".
- 5) When the service is over, please return the headset.